


# INSTRUCTIONS FOR ECONOMY BEVERAGE DISPENSER

PRODUCT NUMBERS 2227, 2228, 2229, 2230



Make sure the spigot with washer is flush with the unit. Position the spigot upside down. Take nut with washer and screw on the end of the shank until hand tight. Continue to hold nut and turn spigot to the right until it is in its normal vertical position (180°).

P.O. Box 53006  
Oklahoma City, Oklahoma 73152-3006  
(405) 528-3011 • FAX (405) 528-6338  
1-800-654-8210  
#104803301 Rev. 10/02

European Distribution Center:  
Edisonstraat 84, P.O. Box 110  
6900 AC Zevenaar, The Netherlands  
Tel +31/(0)316-596550 • Telex 45642  
FAX +31/(0)316-340168

**CARLISLE**  
FoodService Products