5842 SLT Product instruction insert

- 1AYLOR
  5842

  1. The timer operates on one LR1130 or LR54 battery (installed). Before use, remove the plastic strip from under the battery cover. Replace the battery when readings grow dim.

  2. Press "MIN" to set minutes.

  3. Press "SEC" to set seconds.

  4. Press "STOP/START" to start timer.

  5. To pause, press "STOP/START". Press to start timing again.

- 6. When the alarm beeps, press
  "STOP/STARI" to turn off the alarm.
  The timer will recall the last set time.
  Press "MIN" and "SEC" at the same time to reset to zero.

  "The time to reset to zero."
- "START/STOP" when "00 00" displays and the fimer will also count up. Press "START/STOP" when "00 00" displays and the fimer will count up. Press "START/STOP" again to pause and restart timing.

  8. The timer will time up to 99 minutes,
- 59 seconds.

1.7539-

# CLEANING AND CARE:

Clean by hand. Do not completely immerse thermometer in water or put into dishwasher.

ONE YEAR LIMITED WARRANTY: Taylor warrants this product to be free from defects in material or workmanship (excluding batteries), and on return, will repair or replace it at our option, without charge.

# Made in China to our exact specifications.

©2011 Taylor Precision Products and its affiliated companies, all rights reserved. Taylor® is a registered trademark of Taylor Precision Products and its affiliated companies. All rights reserved.

5842 10.11

Front of Insert

Back of Insert

> Date: 10/17/11 Designer: WWCII